G-COD &CNC

PRESENTATION

MAIN CONCEPTS

Introduction

Create method

Some basic commands

Types of control systems

Advantages & disadvantages

Summary

INTRODACTION

- G-code, a programming language used for controlling computerized numerical control (CNC) machines, was established in the early 1960s by the Massachusetts Institute of Technology (MIT). Initially designed for automation and robotics, it evolved into a standard programming language for CNC machines.

- Over time, G-code became widely adopted in computerized manufacturing, enabling operators to precisely control tool and cutting movements on CNC machines. It is crucial for manufacturing complex parts with high accuracy.

- G-code is used to program motion and control tools and axes on CNC machines. Commands in G-code are translated into motion signals for motors and axes, facilitating the production of intricate components.

- As technology and manufacturing industries advance, G-code undergoes continuous improvements to support new features and advanced techniques. New versions are developed to meet the evolving needs of the manufacturing industry.

- In conclusion, G-code plays a fundamental role in operating CNC machines, contributing to precision and efficiency in modern manufacturing.

CREATE METHOD :

1. Designing the Part in SolidWorks:

- **Sketching the Part:**
  - Use drawing commands in SolidWorks to create a 2D sketch of the part.
  - Define dimensions precisely and use relationships to ensure the desired shape.
- **3D Modeling:**
  - Extrude the 2D sketch into the third dimension to create a 3D model of the part.
  - Add details and features to the model to enhance manufacturing accuracy.

2. Setting up Toolpaths in HSMWorks:

- **Tool Selection:**
  - Choose appropriate cutting tools and define their diameters and lengths.
  - Set cutting speeds, feeds, cutting depths, and other relevant parameters.
- **Toolpath Settings:**
  - Specify the tools used in turning, milling, and drilling operations.
  - Define cutting angles and other details to match the part's requirements and the machine capabilities.

3. Tool Simulation:

- **Check for Interference:**
  - Use HSMWorks simulation to analyze toolpaths and ensure there is no interference with the part or other tools.
- **Programming Refinement:**
  - Update programming settings based on simulation results to improve efficiency and avoid errors.

CREATE METHOD :

4. Machine Setup:

- **Zero Point Definition:**
  - Specify the machine's zero point on the part or the table.
  - Set dimensions of the part concerning the zero point.
- **Machine Configuration:**
  - Choose the type of CNC machine and configure its settings such as tool speed and movement.

5. Exporting Programming:

- **Selecting Operations:**
  - Choose the operations to include in the programming, such as turning, milling, and drilling.
- **Save the Programming:**
  - Export the programming in G-code format.
  - Save the file to a suitable location, and provide a clear name.

6. Loading Programming onto the CNC Machine:

- **File Transfer:**
  - Transfer the programming file to the CNC machine using a method such as USB or network.
- **Loading the Programming:**
  - Load the programming onto the CNC machine's control unit.
  - Specify required variables, such as zero point and part dimensions.

7. Testing and Machine Adjustment:

- **Running the Program:**
  - Run the program on the CNC machine and monitor the process.
- **Optimizing Settings:**
  - If any issues arise, refine machine settings or programming and rerun.

AN EXPLANATION VIDEO OF THE PROCESS

AN EXPLANATION VIDEO OF THE PROCESS

SOME BASIC COMMANDS

- G-code (The G Command):

Description: G-code is a programming language used to control the movement of CNC machine tools.
Example: G01 X10 Y5 F100 - Moves the tool to coordinates X=10 and Y=5 at a speed of 100 units per minute.

- M-code (The M Command):

Description: M-code is used to activate additional functions or control machine components.
Example: M03 - Turns the spindle clockwise.

- G00 - Rapid Positioning:

Description: Moves the tool rapidly to the destination without turning on the spindle.

- G01 - Linear Movement:

Description: Moves the tool linearly to the destination at a specified speed.

- F - Feed Rate:

Description: Specifies the feed rate or movement speed when using G01. For example, F100 means a feed rate of 100 units per minute.

- S - Spindle Speed:

Description: Specifies the spindle rotation speed. For example, S2000 means 2000 revolutions per minute.

TYPES OF CONTROL SYSTEMS

1. **Fanuc:** The Fanuc CNC control system is widely recognized for its performance and stability, commonly used in the CNC machining industry.
2. **Siemens:** Siemens CNC control provides precise control and is utilized in operating advanced CNC machines.
3. **Mazak:** Mazatrol CNC control by Mazak is known for its user-friendly interface and is employed in a variety of CNC machining applications.
4. **Haas Automation:** Haas offers its own CNC control system known for its reliability and easy integration.
5. **Heidenhain:** Heidenhain CNC control system offers high precision and is employed in applications requiring accurate measurements.
6. **Okuma:** Okuma's CNC control system is utilized in advanced and multi-axis CNC machines.
7. **Fagor Automation:** Fagor Automation provides CNC control panels for a diverse range of industrial applications.

ADVANTAGES & DISADVANTAGES

Advantages of CNC (Computer Numerical Control):

1. **Precision and Accuracy:** CNC machines offer exceptional precision and accuracy in machining processes, leading to high-quality and consistent results.
2. **Efficiency:** CNC machines operate continuously without the need for breaks, resulting in increased efficiency and productivity.
3. **Versatility:** CNC machines can be easily reprogrammed for different tasks, making them versatile for various manufacturing applications.
4. **Complex Geometries:** CNC machines excel at producing complex shapes and

Disadvantages of CNC:

1. High Initial Cost: The initial investment in CNC machines is significant, making them less accessible for small businesses or startups.

2. Skilled Operator Requirement: Skilled operators are needed for effective programming and operation of CNC machines, leading to higher labor costs.

3. Programming Complexity: CNC programming requires expertise, and errors in the code can result in defective parts or damage to the machine.

4. Limited Feeling for Materials: CNC machines lack the tactile feedback of manual machining, which can make handling certain materials more

SUMMARY

- CNC Machines (Computer Numerical Control):

- CNC machines are advanced manufacturing tools widely used in the industry. The key feature of these machines is their ability to operate automatically based on programmed instructions. Here's a brief overview:

- Programming using G-code:

- G-code Programming Language: Used to command and control CNC machines, specifying their movements. For example, G01 denotes linear motion.
- Precision and Accuracy:

- High Accuracy: CNC machines exhibit high precision in producing intricate and accurate components due to precise tool movement.
- Automated Control:

- Automatic Operations: CNC machines perform numerous tasks automatically based on programmed instructions, enhancing overall efficiency.
- Flexibility for Production Changes:

- Manufacturing Flexibility: Programming adjustments allow easy adaptation to produce various types of components.
- Versatile Applications:

- Diverse Industry Applications: CNC machines are employed across various industries such as automotive, aerospace, 3D printing, and more.
- Time and Labor Savings:

- Increased Productivity: Reduction in production time and improved efficiency contribute to increased overall productivity.
- Motion and Tool Control:

- Precise Motion Control: CNC machines provide precise control over tool movement and multiple axes.
- Advanced Programming:

- Utilization of Modern Technology: Programming using computers allows control over various aspects of the machining process.

THANK YOU

HUSSEIN AMMAR ALLAMI

2024/2/27